



TAKE IT EASY.

# How to Maximize Weight Rating on LockNLoad

By increasing the number of attachment points you can increase the carrying capacity of the LockNLoad platform. In some instances you must add additional connection points.

## LockNLoad Installed Using SL Adapter



### INSTALLATION:

In this scenario, LockNLoad is installed to the roof of your vehicle with at least 4 StreamLine Towers, either TimberLine or SkyLine, and the LockNLoad SL Adapter.

### HOW TO INCREASE LOAD RATING:

To increase load capacity on Platforms J, E, N, and C only, add more SkyLine or TimberLine Towers paired with SL Adapters.



### PRODUCTS:

LockNLoad SL Adapter SET of 2 | #8005042

### DEPENDING ON YOUR VEHICLES ROOF, ADD THE CORRELATING TOWERS.

TimberLine Towers SET of 2 | #8000151\*

SkyLine Towers SET of 2 | #8000152\*

\*Plus vehicle specific Landing Pads, sold separately

## LockNLoad Installed To Existing Roof Rack\*\*



### INSTALLATION:

In this scenario, LockNLoad is installed to your existing roof rack with at least 4 Crossbar Clamps attached to 2 Crossbars.

### INCREASE LOAD RATING:

To increase load capacity add more Crossbars with Towers, and Crossbar Clamps.

### PRODUCTS:

LockNLoad Clamps SET of 2 | #8005039

### DEPENDING ON YOU'RE VEHICLES ROOF, ADD THE CORRELATING TOWERS.

VISIT [YAKIMA.COM](http://YAKIMA.COM) TO FIND YOUR ROOF RACK.

\*\*Your vehicle roof weight limit may not allow the increase in capacity. This can be found in your vehicle users manual.



LockNLoad Crossbar Clamp

## LockNLoad Installed to a Truck Bed Rack

Truck racks include: OverHaul HD, OutPost HD, BedRock HD, BedRock, and Outdoorsman

Platforms J, E, C, and H only, are sold with the maximum number of clamps or adapters. You cannot add any more attachment points to increase the weight capacity further.

