


LOCKN'LOAD" PLATFORM INBOARD LIGHT BRACKET KIT

MAX LOAD RATING: 8KG

FIRST TIME INSTALLATION

- Please read instructions carefully before installation.
- Check the contents of kit. Contact your YAKIMA dealer if any parts appear missing or damaged.
- Clean your Platform prior to fitting the LOCKN'LOAD Platform Inboard Light Bracket Kit.
- Place these instructions in the vehicle's glove box after installation is complete.



KIT CONTENTS ITEM COMPONENT QTY 1. Inboard Light Bar **x**1 Bracket Right Bend 2. Inboard Light Bar **x**1 **Bracket Left Bend** 3. Nyloc Nut x4 4. Washer х4 х4 5. T Bolt


80-13-037-Rev2


LIGHT BAR INSTALLATION



CONFIGURATIONS

The Light Bar Brackets can be mounted to the Platform in two different orientations to suit side or top mounted light bars as shown.





REMOVE DEFLECTOR OR RUBBER INFILL


If mounting to the front of the Platform, remove the deflector. If mounting to the rear of the Platform remove the rubber infill.

This is done by simply peeling the part out of the slot, starting at one end and working across the length of the strip.


Installation is the reverse and should be confirmed by hearing an audible 'CLICK' when it is fully installed.


LOOSELY ATTACH BRACKETS TO LIGHT BAR

Using the hardware supplied with your light bar, loosely attach brackets to each end of the light bar in the applicable orientation. If mounting light bar via the side, four mounting holes are available to suit your size and style of light bar.




80-13-037-Rev2 2/4






80-13-037-Rev2 3/





SECURE LIGHT BAR TO PLATFORM

Secure light bar and bracket assembly to the Platform by tightenting each Nyloc Nut to 4Nm using a 10mm Socket Wrench or Spanner.






ADJUST LIGHT BAR AND TIGHTEN SCREWS

Adjust light bar to preferred angle then tighten light bar hardware installed in Step 3 according to the manufacturer's instructions.

Installation is now complete.

Ensure all screws are regularly checked and tightened to ensure minimal bounce and maximum safety.

Ensure all wiring is retained according to Light Bar manufacturer instructions.





www.yakima.com.au

YAKIMA AUSTRALIA PTY. LTD

17 Hinkler Court Brendale, QLD 4500 Australia 1800 143 548

YAKIMA EUROPE

Twentehaven 7 3433 PT Nieuwegein The Netherlands +31 2080 81425

YAKIMA PRODUCTS, INC.

4101 Kruse Way Lake Oswego, OR 97035-2541 USA 888 925 4621