

MOD Vehicle Guidelines

How to select the right MOD System for your vehicle

STEP 1

Identify Tie-Down Points in Cargo Space

Does your vehicle have 4 tie-downs? If not, you need a custom tie-down solution.* (refer to image for tie-down examples labeled with arrows)

Do the tie-downs feel robust? Do the tie-downs have metal attachment hardware? If not, you need a custom tie-down solution.*

STEP 2


Take Measurements


Measure the space between your vehicle tie-downs #1 side-to-side and #2 back-to-front. Also measure #3 seat height from the floor (without headrest) and #4 floor to opening or threshold.


Select HomeBase unit using dimensions below based on measurements #1 and #2, keeping in mind tie-downs should be 2" wider than the HomeBase unit in direction #1.

Use measurement #4 to determine if your vehicle requires a MOD Riser Kit. If the threshold of your hatch measures more than 2" from the floor anywhere along the width of the HomeBase unit, you will need a MOD Riser Kit. If this measurement is greater than 4.5" the MOD system will not work in your vehicle.

Helpful Tip: Look for any other obstructions (wheel wells, narrow hatch opening, speakers, or spare tires) that may interfere with the installation of MOD. If any of these exist, measure the smallest dimension and compare to the specifications below.








STEP 3

Configure Your System

Using measurement #4 and keeping in mind you cannot START the upper level of the MOD System higher than the rear seat back (excluding headrest), compare seat height to measurements below to build the system.

Keep in mind the recline of the rear seat may require to you go to a smaller size HomeBase if you plan to use MOD Toppers, GearCrates, or GearTotes.

Rear hatches that slope may also require you to go a size down so the hatch does not interfere with the MOD System. Yakima recommends 2" of clearance from the rear hatch/glass.



*Need a custom solution for tie-down points? Or confused by any information in this sheet?

Contact an authorized Yakima MOD System Dealer.

Custom installation at user's own risk.